

8-channel Pt100/Pt1000 temperature to Modbus TCP and MQTT network data acquisition module WJ285

Product features:

- Convert 8-channel Pt100/Pt1000 thermistor to standard Modbus TCP protocol
- Supports communication protocols such as TCP Server, UDP, MQTT, etc
- Built in web page function, data can be queried through web pages
- Standard 3-wire measurement method with automatic long line compensation
- Using a 12 bit AD converter, the measurement accuracy is better than 0.1%
- The accuracy of the calibration module can be programmed through the network
- Wide power supply range: 8~32VDC
- High reliability, easy programming, and easy application
- Standard DIN35 rail installation, convenient for centralized wiring
- Users can set module IP addresses and other parameters on the webpage
- Low cost, small size, modular design
- Dimensions: 106 mm x 59mm x 37mm

Typical applications:

- Signal measurement, monitoring, and MQTT reporting
- TCP network, data collection
- Intelligent building control, security engineering and other application systems
- Industrial automation control system **diagram** of TCP network,
- Equipment operation monitoring, MES system
- Measurement of sensor signals
- Acquisition and recording of industrial field data
- Development of medical and industrial control products
- Pt100/Pt1000 temperature signal measurement

Product Overview:

The WJ285 product is an IoT and industrial Ethernet acquisition module that enables transparent data exchange between sensors and networks. The analog data from sensors can be forwarded to the network.



WJ285 module appearance diagram




Figure 2 Internal Block Diagram of WJ285 Module

The WJ285 series products include power conditioning, Pt100/Pt1000 temperature signal acquisition, and RJ-45 network interface communication. The communication method adopts MODBUS TCP protocol. TCP is a transport layer based protocol that is widely used and a reliable connection oriented protocol. Users can directly set module IP

addresses, subnet masks, etc. on the webpage. Can be used for monitoring and controlling the operation of sensor devices.

The WJ285 series products are intelligent monitoring and control systems based on microcontrollers, where user set module IP addresses, subnet masks, and other configuration information are stored in non-volatile memory EEPROM.

The WJ285 series products are designed and manufactured according to industrial standards, with strong anti-interference ability and high reliability. The working temperature range is -45 °C to +80 °C.

Function Introduction:

The WJ285 remote I/O module can be used to measure 8 Pt100/Pt1000 temperature signals.

1. Temperature signal input

12 bit acquisition accuracy, 8 temperature signal inputs. Measure temperature range -200~600 degrees. The product has been fully calibrated before leaving the factory. During use, users can also easily program and calibrate themselves.

2. Communication Protocol

Communication interface: RJ-45 network interface. The two indicator lights at the network port position, the Link light (green light) stays on and the Data light (yellow light) stays on after the network cable is plugged in.

Communication protocol: MODBUS TCP protocol is adopted to achieve industrial Ethernet data exchange. It can also communicate with modules through TCP sockets.

Network cache: 2K bytes (for both sending and receiving)

Communication response time: less than 10mS.

3. Anti interference

There is a transient suppression diode inside the module, which can effectively suppress various surge pulses and protect the module.

Product model:

WJ285 - Z□ - RJ45

Input type: Z □		Communication interface: RJ45	
code	explain	code	explain
Z1	PT100, -200~600°C	RJ45	Output as RJ-45 network interface
Z5	PT1000, -200~600°C		

Selection example 1: Model: **WJ285-Z1-RJ45** represents 8-channel **PT100, -200~600 °C** signal input, and output is RJ-45 network interface

Selection Example 2: Model: **WJ285-Z5-RJ45** represents 8-channel **PT1000, with -200~600 °C** signal input and RJ-45 network interface output

WJ285 General Parameters:

(Typical @+25 °C, Vs is 24VDC)

Input type: Pt100 input/Pt1000 input

Measurement temperature range: -200~600 °C

Accuracy: 0.1%

Temperature drift: ± 50 ppm/°C (± 100 ppm/°C, maximum)

Bandwidth: -3 dB 10 Hz

Conversion rate: 16FPS (factory default value, users can modify the conversion rate on the webpage.)

You can set the AD conversion rate to 2SPS, 4SPS, 8SPS, 16SPS, 32SPS, 50SPS, 80SPS, 100SPS by sending commands

Common mode rejection (CMR): 120 dB (1k Ω Source Imbalance @ 50/60 Hz)

Normal mode suppression (NMR): 60 dB (1k Ω Source Imbalance @ 50/60 Hz)

Input protection: overvoltage protection, overcurrent protection

Communication: MODBUS TCP communication protocol or TCP socket character protocol or MQTT protocol

Web page: Supports web access module and web page setting module parameters.

Interface: RJ-45 network interface.

Communication response time: 100 ms maximum

Working power supply: +8~32VDC wide power supply range, with internal anti reverse and overvoltage protection circuits

Power consumption: less than 3W

Working temperature: -45~+80 °C

Working humidity: 10~90% (no condensation)

Storage temperature: -45~+80 °C

Storage humidity: 10~95% (no condensation)

Dimensions: 106 mm x 59mm x 37mm

Pin definition and wiring:

Pin	name	Description	Pin	name	Description
one	A0	The A end of the input channel 0 of the thermistor	14 (Ethernet port)	RJ-45	RJ-45 network interface
two	B0	B1 terminal of input channel 0 of thermistor			
three	GND2	Simulate signal ground, B2 terminal of thermistor input			
four	A1	Terminal A of input channel 1 for thermistor			
five	B1	B1 terminal of thermistor input channel 1			
six	A2	Terminal A of thermistor input channel 2	fifteen	A5	Terminal A of input channel 5 for thermistor
seven	B2	B1 terminal of thermistor input channel 2	sixteen	B5	B1 terminal of thermistor input channel 5
eight	A3	Terminal A of input channel 3 for thermistor	seventeen	GND2	Simulate signal ground, B2 terminal of thermistor input
nine	B3	B1 terminal of thermistor input channel 3	eighteen	A6	Terminal A of input channel 6 for thermistor
ten	A4	Terminal A of input channel 4 for thermistor	nineteen	B6	B1 terminal of thermistor input channel 6
eleven	B4	B1 terminal of thermistor input channel 4	twenty	GND2	Simulate signal ground, B2 terminal of thermistor input
twelve	PW+	Positive end of power supply	twenty-one	A7	Terminal A of input channel 7 for thermistor
thirteen	GND	Negative end of power supply	twenty-two	B7	B1 terminal of thermistor input channel 7

			0	
--	--	--	---	--

Note: The pins with the same name are internally connected






Figure 3 Wiring diagram of WJ285 module

Configure WJ285 module through computer



1. Connect the module directly to the computer via Ethernet cable and provide power to the module.



2. Open the computer "Ethernet" - "Properties" - "Internet Protocol Version 4 (TCP/IPv4)" - Set the computer IP and other information as follows:

“
IP address: 192 168 . 0 eight
Subnet mask: 255 255 . 255 . 0
Default gateway: 192 168 . 0 one
”



3. Open a browser to access: "192.168.0.7"

参数设置

采样速率

100 SPS

网络配置

工作方式

TCP Server

本地IP设置

手动设置IP

MAC地址

4A:8E:BF:7F:ED:7C

IP地址

192.168.0.7

默认网关

192.168.0.1

子网掩码

255.255.255.0

本地端口

23

自动上报时间间隔(ms)

0

模块名称

4A8EBF7FED7C

MQTT设置

关闭MQTT功能

保存并重启

Mac地址:4A:8E:BF:7F:ED:7C; 版本:1.0

Click on '[Configure Module Parameters](#)' to set module parameters, as shown in the figure

数据显示

温度值

通道0:299.542969 °C
 通道1:666.659973 °C
 通道2:666.659973 °C
 通道3:666.659973 °C
 通道4:666.659973 °C
 通道5:666.659973 °C
 通道6:666.659973 °C
 通道7:666.659973 °C

Click on '[View Data Online](#)' to view module data, as shown in the figure

```
{
  "dataRate": "0",
  "workmode": "0",
  "setIP": "",
  "mac": "D4FD4FA54F1F",
  "ipAddress": "192.168.0.7",
  "gateway": "192.168.0.1",
  "netmask": "255.255.255.0",
  "localPort": "23",
  "remotePort": "23",
  "remoteServerIp": "192.168.0.160",
  "sendTime": "0",
  "devName": "D4FD4FA54F1F",
  "setMQTT": "0",
  "mqttHostUrl": "broker.emqx.io",
  "clientId": "D4FD4FA54F1F",
  "username": "",
  "passwd": "",
  "topic": "/wayjun/pub",
  "port": "1883",
  "pubTime": "5000",
  "subtopic": "/wayjun/sub"
}
```

Click on '[Json Batch Configuration](#)' to batch configure modules, as shown in the figure

Character Communication Protocol:

MQTT protocol: After a successful connection, a command is sent to the [MQTT subscription topic](#) of the module, and the replied data is displayed on the [MQTT publication topic](#) of the module.

Under working modes such as **TCP Server, TCP Client, UDP Mode, Web Socket, etc.:** After a successful connection, commands can be sent and data can be received.

1、 Read data command

Send: # 01 (If timed automatic reporting is set, there is no need to send commands, the module will report data at regular intervals)

Reply: {"time": "194685", "devname": "D4FD4FA54F1F", "temp": [-74.434761, -666.659973, -666.659973, -666.659973, -666.659973, -666.659973]}

Format Description:

The module name 'devName' can be modified on the webpage as needed

The internal time of the 'time' module, measured in mS.

The temperature data collected by the "temp" module is in °C.

You can also read a single set of data:

```
#01>temp                reply: {"temp": [300.253647, -666.659973, -666.659973, -666.659973, -666.659973,-666.659973,-666.659973,-666.659973]}
```

2. Read configuration commands

The configuration parameters of the reading module can also be viewed directly on the webpage.

Send: % 01ReadConfig

Reply: {"version": "V1.0", "dataRate": 7, "setIP": 1, "mac": "4A:8E:BF:7F:ED:7C", "ipAddress": "192.168.0.7", "gateway": "192.168.0.1", "netmask": "255.255.255.0", "work mode": 0, "localPort": 23, "remotePort": 23, "remoteServerIP": "192.168.0.160", "sendTime": 0, "devName": "4A8EBF7FED7C", "setMQTT": 0, "mqttHostURL": "broker.emqx.io", "client ID": "4A8EBF7FED7C", "username": "", "passwd": "", "topic": "/wayjun/sub", "port": 1883, "pubTime": 5000, "subtopic": "/wayjun/sub" }

3. Set configuration commands

The configuration parameters of the module can also be set directly on the webpage. You can set all or some parameters, and the module will automatically restart after setting.

send out:


```
%01WriteConfig{"version":"V1.0","dataRate":7,"setIP":1,"mac":"4A:8E:BF:7F:ED:7C","ipAddress":"192.168.0.7","gateway":"192.168.0.1","netmask":"255.255.255.0","workmode":0,"localPort":23,"remotePort":23,"remoteServerIp":"192.168.0.160","sendTime":0,"devName":"4A8EBF7FED7C","setMQTT":0,"mqttHostUrl":"broker.emqx.io","clientId":"4A8EBF7FED7C","username":"","passwd":"","topic":"/wayjun/pub","port":1883,"pubTime":5000,"subtopic":"/wayjun/sub" }
```

You can also set only a single parameter, such as modifying IP: % 01WriteConfig {"ipAddress": "192.168.0.7"}

Reply: ! 01 (cr) indicates successful setting? 01 (cr) indicates a command error

Modbus TCP protocol

The module defaults to one Modbus TCP Server at the factory, no need to set it up, just communicate according to the Modbus TCP protocol. If more Modbus TCP servers are needed, please change the module's working mode to Modbus TCP in the configuration parameters. Supports up to 6 Modbus TCP servers.



(1) Modbus TCP data frames:

Transmission over TCP/IP Ethernet, supporting Ethernet II and 802.3 frame formats. As shown in Figure 3, the Modbus TCP data frame consists of three parts: packet header, function code, and data.




Figure 6: Request/Response of MODBUS on TCP/IP

(2) MBAP message header description:

The MBAP header (MBAP, Modbus Application Protocol, Modbus Application Protocol) is divided into 4 fields, totaling 7 bytes, as shown in Table 1.

Table 1: MBAP Message Header

Domain	Length (B)	Description
Transmission identification	2 bytes	Indicate the transmission of a MODBUS query/response
Protocol Logo	2 bytes	0=MODBUS protocol
Length	2 bytes	Subsequent byte count
Unit identifier	1 byte	Identification code of remote slave station connected on serial link or other bus

(3) Modbus function code:

Modbus function codes are divided into three types, namely:

- (1) Public Function Code: Defined function codes that ensure their uniqueness and are recognized by Modbus.org;
- (2) There are two sets of user-defined function codes, namely 65-72 and 100-110, which do not require approval but do not guarantee the uniqueness of code usage. If it becomes public code, it needs to be approved by RFC;
- (3) The reserved functional code, which is used by certain companies on certain traditional devices, cannot be used for public purposes.

Among the commonly used public function codes, WJ89 supports some function codes, as shown below:

Function code	name	explain
03	Read Holding Register	Read and hold register 1 represents high level, 0 represents low level.

(4) Description of supported function codes

03 (0x03) Read hold register

In a remote device, use this function code to read the contents of consecutive blocks in the hold register. The request PDU specifies the starting register address and the number of registers. Address registers from scratch. Therefore, addressing registers 1-16 are 0-15. In the response message, each register has two bytes, with the first byte being the data high bit and the second byte being the data low bit.

Example of function code 03, read input analog quantity, register address 40001:

request			response		
Field Name		hexadecimal	Field Name		hexadecimal
MBAP message header	Transmission identification	01	MBAP message header	Transmission identification	01
		00			00
	Protocol Logo	00		Protocol Logo	00
		00			00
length	00	length	00		
	06		05		
Unit identifier	01	Unit identifier	01		
Function code		03	Function code		03
Starting address Hi		00	Byte count		02
Starting address Lo		00	Register value Hi (0x00)		00
Register number Hi		00	Register value Lo (DI7-DI0)		00
Register number Lo		01			

Register address description for WJ285 (note: addresses are all decimal numbers)

Supports registers with function code 03.

Address 4X (PLC)	Address (PC, DCS)	Data content	attribute	Data Explanation
forty thousand and eleven	ten	Channel 0 integer temperature value	read-only	The measured temperature data, signed integer, divided by 10 equals the actual temperature. If the data is -8888, it indicates a short circuit in the thermal resistance, If the data is 8888, it indicates a thermoelectric blocking line.
forty thousand and twelve	eleven	Channel 1 integer temperature value	read-only	
forty thousand and thirteen	twelve	Channel 2 integer temperature value	read-only	
forty thousand and fourteen	thirteen	Channel 3 integer temperature value	read-only	

forty thousand and fifteen	fourteen	Channel 4 integer temperature value	read-only	
forty thousand and sixteen	fifteen	Channel 5 integer temperature value	read-only	
forty thousand and seventeen	sixteen	Channel 6 integer temperature value	read-only	
forty thousand and eighteen	seventeen	Channel 7 integer temperature value	read-only	
40031~40032	30~31	Channel 0 floating point temperature value	read-only	<p>Measured temperature data, 32-bit floating-point number, For example, channel 0, the low 16 bits are in register 40031, The high 16 bits are in register 40032, and the same applies to other channels.</p> <p>If the data is -888.88, it indicates a short circuit in the thermal resistance, If the data is 888.88, it indicates a thermoelectric blocking line.</p>
40033~40034	32~33	Floating point temperature value of channel 1	read-only	
40035~40036	34~35	Floating point temperature value of channel 2	read-only	
40037~40038	36~37	Floating point temperature value of channel 3	read-only	
40039~40040	38~39	Channel 4 Floating Point Temperature Value	read-only	
40041~40042	40~41	Channel 5 Floating Point Temperature Value	read-only	
40043~40044	42~43	Channel 6 Floating Point Temperature Value	read-only	
40045~40046	44~45	Floating point temperature value of channel 7	read-only	
forty thousand two hundred and eleven	two hundred and ten	Module Name	read-only	High bit: 0x02 Low bit: 0x85

Calibration module:

The product has been calibrated before leaving the factory, and users can use it directly without calibration.

During use, you can also use the product's calibration function to recalibrate the module. When in school, the module needs to input appropriate signals, and different input ranges require different input signals.

To improve calibration accuracy, it is recommended to use the following equipment for calibration:

1. A high-precision resistor box that can be precise to 0.01 ohms

Calibration process

1. Connect the corresponding input signal to the channel that needs to be calibrated according to the input range of the module.

2. Input 0 ohms to the WJ285 module.

3. After the signal stabilizes, send \$01 {"calibrationCHx": 0} to the WJ285 module, where x has a value range of 0-7, representing 8 channels. The module will perform zero calibration.

4. Input the resistance signal corresponding to 600 degrees to the WJ285 module.

For example, Pt100, with a full range of 600 degrees, adjust the resistance of the resistance box to 313.708 ohms

For example, Pt1000, with a full range of 600 degrees, adjust the resistance of the resistance box to 3137.08 ohms

5. After the signal stabilizes, send \$01 {"calibrationCHx": 1} to the WJ285 module, where x has a value range of 0-7, representing 8 channels. The module will undergo full calibration.

1、 Calibration completed.

Common problems with WJ285

1. Cross network segment issues

If the IP of the device and the communicating PC are not in the same network segment and are directly connected via Ethernet or under the same sub router, then the two cannot communicate at all.

give an example:

Device IP: 192.168.0.7

Subnet mask: 255.255.255.0

PC's IP: 192.168.1.100

Subnet mask: 255.255.255.0

Due to the device's IP being 192.168.0.7, it is unable to log in to the device's webpage or ping it on the PC.

If you want the two to communicate, you need to set the subnet mask of the device and PC, as well as the subnet mask on the router, to 255.255.0.0, so that you can log in to the module webpage.

2. The device can ping, but the webpage cannot be opened

There may be several reasons for this:

1) The device has set a static IP address that conflicts with the IP addresses of existing devices in the network

2) The HTTP server port has been modified (default should be 80)

3) Other reasons

Solution: Reset the device to an unused IP address; Restore factory settings or enter the correct port when opening the browser.

3. Every once in a while, there is a disconnection and reconnection

Every once in a while, there will be a phenomenon of disconnection and reconnection

Reason: There is an issue of IP address conflict between the serial server and other devices

4. Communication is abnormal, network connection cannot be established, or search cannot be found

The firewall of the current computer needs to be turned off (in the Windows firewall settings)

Three local ports must not conflict, meaning they must be set to different values. Default values are 23, 26, and 29

Having illegal MAC addresses, such as full FF MAC addresses, may result in inability to connect to the target IP address or duplicate MAC addresses.


Illegal IP addresses, such as network segments that are not in the same network segment as the router, may not be able to access the external network.

5. Hardware problem search

Poor power supply from the power adapter or poor contact of the plug

If the power light and network port light are not on, it means there is no power supply or the hardware is broken.

Dimensions: (Unit: mm)



Can be installed on standard DIN35 rails

guarantee:

Within two years from the date of sale, if the user complies with the storage, transportation, and usage requirements and the product quality is lower than the technical specifications, it can be returned to the factory for free repair. If damage is caused due to violation of operating regulations and requirements, device fees and maintenance fees shall be paid.

Copyright:

Copyright © 2024 Shenzhen Weijunrui Technology Co., Ltd.

Without permission, no part of this manual may be copied, distributed, translated, or transmitted. This manual is subject to modification and update without prior notice.

Trademark:

The other trademarks and copyrights mentioned in this manual belong to their respective owners.

Version number: V1.0

Date: September 2024